

# Why do I need an autoclave cap?

Put the cap on the electrode before autoclaving it. This keeps the connector dry, which insures proper electrode performance.



---

The contents of this publication are presented for information purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding products or services described herein or in their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the design or specification of such products at any time.

© 2024 Broadley-James Corporation. All rights reserved. Visit [www.broadley-james.com/trademarks](http://www.broadley-james.com/trademarks) for trademark information.

TMP-BF-102101

**North America and Pacific**

Email: [sales@broadleyjames.com](mailto:sales@broadleyjames.com)  
Web: [www.broadleyjames.com](http://www.broadleyjames.com)

19 Thomas, Irvine CA, 92618 USA

Phone: 949-829-5555  
Tollfree: 800-288-2833  
Fax: 949-829-5560

**United Kingdom and EU Countries**

Email: [sales@broadleyjames.co.uk](mailto:sales@broadleyjames.co.uk) Phone: +44 (0)1525 862518  
Web: [www.broadleyjames.eu](http://www.broadleyjames.eu) Fax: +44 (0)1525 862811

Wrest Park, Silsoe Beds MK45 4HS, UK